

2023

STOCK RECOMMENDATION LIST

K 1270



HEADING	PART NUMBER	DESCRIPTION	QTY INSTALLED ON MACHINE	RECOMMENDED STOCK QTY PER 20 MACHINES	K 1270	K 1270 RAIL
Service Kit	599 15 65-03	Air filter, Fuel filter, Service tool, Spark plug, Cord, Belt			•	
Air Filter	510 24 41-03	Air Filter*	1	10	•	
	510 24 41-05	Air Filter	1	10		•
Belt Guard	503 14 51-01	Clutch Spring	3	12	•	•
	503 14 49-03	Clutch Assy	1	4	•	•
	588 80 92-02	Driving Pulley Assy	1	1	•	•
Belt Guard & Pulley	544 97 63-01	Belt*	1	10	•	•
	506 27 92-06	Belt Guard	1	2	•	
	506 27 92-07	Belt Guard Rail 14"	1	2		•
	506 27 92-08	Belt Guard Rail 16"	1	2		•
	589 39 03-03	Bearing Housing	1	2	•	
Blade Guard	578 11 05-01	Pulley	1	1	•	•
	578 39 82-01	Bushing	1	2	•	•
	584 43 78-01	Shim	2	2	•	•
	584 43 79-01	Lining	1	1	•	•
	584 43 80-01	Lining	1	1	•	•
	583 87 44-02	Flange Washer 105mm	2	10	•	
Carburator	506 07 09-02	Flange Washer 119mm (JP) 14", 16"	2	10	•	•
	597 85 70-01	Carburettor	1	2	•	•
Crankcase	585 28 09-01	Gasket	1	2	•	•
Cylinder, Piston & Muffler	582 58 23-03	Cylinder Assy	1	2	•	•
	505 41 79-05	Muffler Assy	1	2	•	•
Engine Kit	582 41 50-06	Crankcase Long Block	1	1	•	•
Fuel Tank	598 83 66-01	Fuel Filter*	1	10	•	•
	540 05 49-01	Purge	1	1	•	•
Hose	581 47 62-14	Hose Kit	1	1	•	
	581 72 15-10	Hose Kit	1	1	•	
Housing	576 66 57-10	Bearing Housing Rail 14"	1	1		•
	576 66 57-12	Bearing Housing Rail 16"	1	1		•
	576 66 57-13	Bearing Housing Rail 16" (US)	1	1		•
	506 22 75-01	Sleeve	2	2		•
Ignition System	503 23 51-11	Spark Plug*	1	10	•	•

HEADING	PART NUMBER	DESCRIPTION	QTY INSTALLED ON MACHINE	RECOMMENDED STOCK QTY PER 20 MACHINES	K 1270	K 1270 RAIL
Ignition System	503 23 51-11	Spark Plug	1	10	•	•
	580 38 05-07	Ignition Module	1	2	•	•
	587 24 88-01	Flywheel Assy	1	1	•	•
Rail Fixture	596 47 43-01	Knob	2	2		•
	506 23 63-01	Bar	1	10		•
	506 22 77-02	Draw Spring	1	2		•
	503 76 75-01	Dust Cover	1	1		•
	501 04 97-01	Shaft	1	1		•
Starter	506 33 56-25	Starter Cord*	1	10	•	•
	506 27 55-10	Starter	1	2	•	•
	503 74 36-01	Disc	1	2	•	•

